


USER MANUAL



Reading the time

- (1) The watch always indicates the time of the destination set at 12 o'clock.
- (2) The watch has a 2nd hour hand which indicates a.m. or p.m. at the destination set at 12 o'clock.
- (3) The bezel and the watch are currently set for London and the time is 10:10 a.m.

The s- means that this destination is subject to DST (daylight saving time). During DST turn always the bezel to the s-Position.

Setting the time

- (1) Make sure that the bezel is set on the desired destination.
- (2) Pull the crown out to position C
- (3) Turn it until the desired time is reached.
- (4) Push the crown back to position A.




Changing the date

- (1) Pull the crown out to position B
- (2) Turn it until the desired date is reached.
- (3) Push the crown back to position A.


Note: The date can only be moved forward.


Changing the destination

- (1) The bezel and the watch are currently set for London and the time is 10:10 a.m.



- (2) Open the handle





- (3) Turn the bezel and choose the desired destination at 12 o'clock.



- (4) Close the handle
 (5) Read the time at the new destination.
 (6) The watch is now set for Rio and the time is 07.10 a.m.

Note: During DST turn the bezel to the s-Position as Rio is a destination subject to DST.





Recalibrating the date change

The watch always indicates the date of your home/preferred destination. If you choose a new home/preferred destination you must adapt the date change so that it changes at 12 o'clock midnight.

- (1) Pull the crown out to position C and set all hands at 12 o'clock midnight.
- (2) Leave the crown at position C and open the handle.
- (3) Turn the minute hand clockwise as many times over the 12 hour line until the date changes.

The hour hand will not move during this procedure!



- (4) Close the handle. The date change has now been set for the new home destination and the date will always change at 12 o'clock midnight.
- (5) Set the hands forward to the desired time. You may also forward the date by turning the crown on intermediate position B.